



User Manual



Unpair Your Remote

When get the remote **first time**, please remember to do **UNPAIR** action firstly (unpair means remove the previous defective or lost remote firstly, Then can Pair a new remote success), please follow below step:

- ① Install the brand new alkaline battery into remote .
- ② Power on the TV.
- ③ Press the remote key  --- Select TV display **System** menu, Press **OK** key, and select down direction to "**Voice remote**" --- Press **OK**.
- ④ Then Select **Unpair Remote** ---Press **OK** key --- Select **Unpair** , Press **OK** to confirm to **Unpair**, then waiting to see **Unpair complete** on the TV

Pair Your Remote



To begin pairing, press and hold the **Microphone**  and **Mute**  buttons on your voice remote for three seconds, until the light on the remote begins to flash.