Apple Remote Control
User Manual
Model:AP1868AL

Nettech®

What's in the Box ?

1
2
3
4

5

6

8
9

7

AP1868AL

Under the default setting, Only
[TV POWER / INPUT / VOL+/ VOL- / MUTE]
work for TV

1. TV Power

2. LED light

3. OK/Enter

4. Navigation Up/Down/Left/Right

5. Click Once:Home Screen
   Double Click:Switch App
   Hold: Control Center

6. Play/Pause

7. Input

8. TV /Volume

9. MUTE

Section 3:Learning Function | 02

Please make sure you have our remote
and your original TV remote controls in
hand and they do have working batteries
inside.

Step 1: Hold our AP1868AL remote, press [Power]
and [VOL+] together for about 5 seconds till
the LED indicator is on, it will enter the learning
mode

Section 3:Learning Function | 03

Step 2: Hold the original remote approximately
3cm from our AP1868AL remote,
pointing towards as shown below:

AP1868AL   ORIGINAL

1~3cm

Step 3: Start to learn the buttons one by one

Quick Start

No program needed

Nettech

In most cases, this apple remote control can be directly used without any set up, If your TV brand and apple TV box meet the following requirements.

Setion 1: Requirements

One

Your Apple Remote AP1868AL uses IR technology(Infrared),it **works with only one Apple TV** at a time. If there are other Apple devices with IR(for example an Mac or second Apple TV), please connect our remote to your primary Apple TV [Detail in Section 2 connect remote] to prevent interference. If not, you can skip this set up.

Section 3:Learning Function | 04

For example to learn the TV power button, please press and hold the [**TV power**] button on the **original remote**(do not release),till the LED light on **AP1868AL remote** start flash, If the LED light on AP1868AL didn't flash. Please move the original remote in order to find the signal window point correctly as shown below. (move left or right,up or down)

AP1868AL   ORIGINAL

1~3cm

signal window in the midde

Section 3:Learning Function | 05

ORIGINAL
AP1868AL

1~3cm

signal window on the left

AP1868AL   ORIGINAL

1~3cm

signal window on the right

When the LED on AP1868AL start flash, release the button on the original remote press the [**TV POWER**] button on our AP1868AL remote, the LED light on AP1868AL will stay on.

Setion 1: Requirements

Two

Under default setting, AP1868AL can directly control many TV brands.

SAMSUNG	VIZIO
LG	PHILIPS
SONY	PANASONIC
TOSHIBA	

already been preload to this remote. The main buttons **[TV POWER]**/ **[INPUT]/[VOL+]/[VOL-]/[MUTE]** should work for those TV brands. If not, you can set up in Section 3 [learning mode].

Compatible types:

Battery Install

① ②

Alkaline battery
AAA 1.5V x 2

It means that you have successfully learned **[TV power]** button.

Step 4: Please repeat step 3 to learn more buttons. If one button is not working, please learn it again

Step 5: To exit the learning mode, hold our AP1868AL remote, press **[Power]** and **[VOL–]** together for about 1 sec the LED light will turn off. It means you have successfully save the above settings.

During the learning mode, if no key is been pressed for more than 25 seconds, it will automatically exit the learn mode. To enter the learn mode, please begin from step 1.

Section 2: Connect Remote to Apple TV

If your apple TV has connected to other remote before, please do the following steps to set our remote as the primary remote, then use it.

1. Turn on your apple TV

2. Point our Apple Remote to your Apple TV, press and hold the **[MENU]** and **[Left]** button for about 6 seconds, until the LED light flashes

3. Done, it should work for your apple TV

4. If it still not working, please repeat step 1 and 2, and press hold for longer time, and try it again.

Other Cool Functions   01

All in One Experience:
If you have other device(for example apple audio), you can also learn it. All in one remote, make better experience

Other Cool Functions   02

Default Function
Back to the default setting, please hold the [input] button and [up] button for 6 seconds, the LED light will flash for 3 times, now it goes back to default setting

Section 3:Learning Function 01

It can only learn Infrared remote control function, **can not learn Bluetooth and wireless remote** control function.

If your **TV brand is not** (SAMSUNG/LG/ SONY/TOSHIBA/VIZIO/PHILIPS/ PANASONIC), please do the following steps to learn the 5 main buttons TV POWER/INPUT/VOL+/VOL-/MUTE

Other Cool Functions 03

Back to last time learn mode
If you already learned remote control before, you would like to return to the last learning state, please do the following setting.

Hold the [**input**] button and [**down**] button for 6 seconds. The LED light will flash for 3 times, now it goes back to the last time learning mode.

Other Cool Functions 04

Compatible with default and Learning Mode
Hold the [**Input**] button and [**OK**] button for 6 seconds. The LED light will flash for 3 times, now it goes back to the following Mode.

Under the Mode setting:

Only [TV POWER] / [INPUT] / [VOL+/ VOL- / MUTE] buttons keep the last time learning mode.

Other buttons back to default setting.

Need more help,video tutorials

https://chilloutlabo.com

Clean Remote for Pet and
Baby Friendly Family